

# Installation Manual

## Multiwrap



**1**

Make sure that the service penetration and the gap are free from dust, dirt and grease.

**2**

$X + \geq 10 \text{ mm}$

Measure the circumference of the service penetration and cut the Multiwrap to size with a knife. Remember to keep an extra length of at least 10 mm to create an overlap.

**3**

Wrap the required number of layers of Multiwrap around the service penetration.

**4a**

Seal the remaining recess with Multimastic SP or with the Multimastic C System or Multimortar System.

**4b**

Caution:  
The Multiwrap may protrude a maximum of 5 mm.

**5**

Fill in the conformity statement and paste it next to the fireproof seal.



For use and for more information about an application, refer to the Mulcol documentation and local and international approvals. See the **Mulcol Fire Protection app** for the correct application in combination with fire resistance, or use our selector at [www.mulcol.com](http://www.mulcol.com) for professional use only.

**MULCOL**  
INTERNATIONAL