

The quick and easy way to insulate pipe work with Tubolit Quick fittings.



STEP 1

Choose the correct Tubolit Quick elbow fitting to match the pipe size to be insulated.



STEP 2

Open the Tubolit Quick fitting and fit around the pipe elbows, locking the teeth together.



STEP 3

Measure and cut a straight section of Tubolit to meet the Tubolit Quick fittings.



STEP 4

Fit the cut Tubolit to the Tubolit Quick fittings.



STEP 5

If required use Tubolit tape or clips to secure any joints.

DONE! a neat and easy installation with Tubolit Quick