

Installation Manual

Multitherm Bandage



1

Seal the opening around the service penetration, according to the sealing method installation instructions. Openings up to 20 mm can easily be sealed with Multimastic SP firestop mastic, over a depth of 10 mm.

2

Make sure the service penetration is free from dust, dirt and grease.

3

Measure the circumference of the service penetration and cut the Multitherm Bandage to size with a knife, as per the installation overview in the box. Remember to keep an extra length of at least 10 mm to create an overlap.

4

Remove the protective film at the back and wrap the Multitherm Bandage around the service penetration. Make sure that the closing side is at the bottom of the service penetration and that the Bandage has a minimum overlap of 10 mm. Press everything down firmly.

5

Fill in the conformity statement and paste it next to the fireproof seal.



Information



Virtual Reality



Augmented Reality

For use and for more information about an application, refer to the Mulcol documentation and local and international approvals. See the **Mulcol Fire Protection app** for the correct application in combination with fire resistance, or use our selector at www.mulcol.com
For professional use only.

MULCOL
INTERNATIONAL